

Hauptständer Centre Stand

Triumph Tiger 900 bis Bj. 98

Montagehinweise

Alle vom Motorrad gelösten Schrauben sind gemäß Herstellerangaben wieder zu montieren, oder mit von SW-MOTECH gelieferten Schrauben zu ersetzen. Falls nicht anderweitig definiert, diese Schrauben nach Tabelle anziehen.

M6	9,6 Nm
M8	23 Nm
M10	46 Nm

Gegebenenfalls Schrauben mit flüssiger Schraubensicherung einkleben.

Prüfen Sie nach 50 km alle Verbindungen auf festen Sitz.

Die Kurvenfreiheit kann durch einen Hauptständer eingeschränkt werden

SW-MOTECH GmbH & Co. KG
Ernteweg 8/10
35282 Rauschenberg
Germany

Tel. +49 (0) 64 25/8 16 8-00
Fax +49 (0) 64 25/8 16 8-10

info@sw-motech.com
www.sw-motech.com

Mounting Instructions

Centerstand cornering clearance:
SW-MOTECH centerstands are carefully designed and tested to eliminate reductions in cornering clearance and ground clearance under most driving conditions on an unmodified stock motorcycle, and are certified to be compliant with European ABE safety standards. Use of any centerstand may reduce cornering clearance or ground clearance under extreme driving situations.





SW-MOTECH products should be installed by a qualified, experienced motorcycle technician. If you are unsure of your ability to properly install a product, please have the product installed by your local motorcycle dealer. SW-MOTECH takes no responsibility for damages caused by improper installation.

All screws, bolts, and nuts, including all replacement hardware provided by SW-MOTECH, should be tightened to the torque specified in the OEM maintenance manual for your motorcycle. If no torque specifications are provided in the OEM maintenance manual, the following torques may be used:

M6	9,6 Nm
M8	23 Nm
M10	46 Nm

All screws, bolts, and nuts should be checked after driving the first 50 km to ensure that all are tightened to the proper torque.

Medium strength liquid thread-locker (i.e., "Locktite") should be used to secure all screws, bolts, and nuts.

1 Hauptständer Centre Stand  HPS.11.121.900 Anzahl/ Pcs. 1	5 Laufbuchse Spacer  HPS.11.121.004 Anzahl/ Pcs. 2
2 Befestigungsblech Fixing Lug  HPS.11.121.901/902 Anzahl/ Pcs. 2	6 Zugfeder Satz Spring Set  ZFD.00.150.011 Anzahl/ Pcs. 1
3 Unterlegscheibe Washer  A 13 DIN 125 Anzahl/ Pcs. 2	7 Ständeranschlag Buffer  HPS.11.121.002 Anzahl/ Pcs. 1
4 Mutter selbstsichernd Lock Nut  M 12 DIN 985 Anzahl/ Pcs. 1	8 Federumlenkung Spring reverse  HPS.11.121.003 Anzahl/ Pcs. 1
	9 Sechskantschraube Hexagon Screw  M12 x 200 DIN 931 Anzahl/ Pcs. 1

! Achtung:
Die Kurven- und Bodenfreiheit kann
durch einen Hauptständer
eingeschränkt werden

Attention:
Cornering and ground clearance can
be reduce by using a centre stand

