

Värmeplatta / Warming plate

Bruksanvisning/User's manual

90071



exxent
Professional cooking

Kundinformation

Läs denna bruksanvisningen noggrant innan du ansluter apparaten för att förhindra skador på grund av felaktig användning.

Kontrollera innan användning

1. Kontrollera att nätspänningen överensstämmer med anvisningen på värmeplattan.
2. Kontrollera så att strömknappen på värmeplattan är avslagen.
3. Kontrollera så att kaffekannen passar värmeplattan. Om det uppstår glapp i botten så att kannan inte får full kontakt med plattan, byt kaffekanna.

Säkerhetsanvisning

4. Värmeplattan ska placeras horisontellt på ett plant underlag med god ventilation. Se till att plattan står stabilt och att det ej finns brandfarliga föremål i närheten. Placera ej värmeplattan på ett fuktigt underlag.
5. Värmeplattan skall enbart anslutas i ett jordat eluttag.
6. Placera den färdigbryggda kaffenkannen på värmeplattan och slå därefter på strömbrytaren.
7. Placera inte en överfylld kaffekanna på värmeplattan då risk för översvämning kan skada plattan.
8. Håll alltid värmeplattan under uppsikt medan den används.
9. Efter användning, slå av strömbrytaren och dra ut sladden ur eluttaget.
10. Skulle ett eventuellt fel upptäckas på värmeplattan, dra ut sladden ur eluttaget. Skicka sedan plattan till din återförsäljare för kontroll.

Kassering av förbrukad apparatur



Enligt lag ska elektriska och elektroniska apparater insamlas och delar av apparaterna återvinnas. Elektriska och elektroniska apparater märkt med symbolen för avfalls-hantering ska kasseras på en kommunal återvinningsstation.

Reklamationsrätt

Enligt gällande lag. Vid reklamation skall apparaten lämnas in där den är inköpt.

Teknisk data

Model: 90072 / BC590-104

230V/50 Hz

60W



MerxTeam AB

Galvaniseringsgatan 5

SE-417 07 Göteborg

Tel: 0046 31 50 67 00

www.merxteam.com

Med reservation för eventuella ändringar.

Customer information

Read this manual carefully before connecting the unit to prevent damage due to improper use.

Check before use

1. Check that the main voltage corresponds to the instructions on the warming plate.
2. Make sure that the power button on the warming plate is turned off.
3. Make sure the coffee pot fits the warming plate. If there is a gap in the bottom so that the jug does not get full contact with the plate, replace the coffee pot.

Safety

4. The warming plate should be placed horizontally on a level surface with good ventilation. Make sure the plate is stable and that there's no flammable objects nearby. Do not place the hot plate on a damp surface.
5. The warming plate must only be connected to a grounded electrical outlet.
6. Place the brewed coffee pot on the warming plate and then turn it on.
7. Do not place a overfilled coffee pot on the warming plate. Flooding can damage the plate.
8. Always keep watch on the warming plate while operating.
9. After use, switch off the power switch and unplug the power cord from the electrical outlet.
10. Should any fault be detected on the warming plate, unplug the cord. Send the plate to your dealer for inspection.

Correct Disposal of this product



This marking indicates that this product should not be disposed with other household wastes throughout the EU. To prevent possible harm to the environment or human health from uncontrolled waste disposal, recycle it responsibly to promote the sustainable reuse of material resources. To return your used device, please use the return and collection systems or contact the retailer where the product was purchased. They can take this product for environmental safe recycling.

Warranty

Warranty according to current law. When raising a claim the appliance must be returned to the store of purchase.

Technical data

Model: 90071 / BC590-104

230V/50 Hz

60W



MerxTeam AB

Galvaniseringsgatan 5

SE-417 07 Gothenburg

Tel: 0046 31 50 67 00

www.merxteam.com

These instructions are subject to alterations or improvements.

