

# How to tie a Barefoot Western Saddle

(except model Barefoot Nevada))



**Step 1** Put on the saddle and fix the western girth to the off-billet on the right side of the saddle.

**Step 2** To fix the girth to the left side, firstly pull the tie-strap (punched long lash through the buckle of the girth from back to front.

**Step 3** Now the tie-strap must be pulled from the front to the back into the saddle's D-ring. Afterwards please lace the tie-strap into the girth buckle again, from back to front.

**Step 4** Fasten the belt is pulling on the tie-strap until the saddle is fixed.

**Step 5** If the desired tension is achieved fix the pin of the girth buckle into the nearest tie strap hole.

**Step 6** he pin must be fixed by raising the top layer of the tie-strap. Securing the pin is important to keep the saddle safe in place.

**Step 7** Secure the end of the tie-strap into the saddle's tie-strap holder.

