

DJURÖ

Lounge and dining range in teak. The armchair is available with the seat and backrest in Batyline textile, or made entirely from teak. The matching footstool is also teak. The dining chair is made entirely from teak or with seat and backrest in Batyline textile. The sunbed has a teak frame and Batyline textile. The range includes two lounge tables and three dining tables.

✓ STOCK ITEM

✉ E-MAIL SALES@SKARGAARDEN.COM FOR LEAD TIME

MATERIAL AND COLOR GUIDE

WOOD



TEAK

DJURÖ LOUNGE ARMCHAIR

Design Matilda Lindblom



EU

PRODUCT

Lounge Chair
W:78 D:66 H:70
Seat height: 36
Armrest height: 55
Weight: 12 kg

PACKAGING

W:85 D:70 H:73
Weight: 18 kg
Volume: 0,43
1 pc per box

US

PRODUCT

W:30.5" D:24.0"
H: 27.5"
Armrest height: 21.5"
Seat height: 14.0"
Weight: 26.5 lb

PACKAGING

W:33.5" D:27.5"
H:29.0"
Weight: 40.0 lb
Volume: 0.027
1 pc per box

DESCRIPTION

✓ Teak

ITEM NO

DJA-TT

TEAK MAINTENANCE

Teak is a hardwood tree, called *Tectona grandis* in latin. Apart from being very stylish, it's also exceptionally durable and it needs very low maintenance. Do note, however, that the latter isn't the same as "no maintenance". Below are a few tips on what to do, and what not to do.

At Skargaarden we only use only high grade teak, harvested from carefully controlled plantations. You don't have to use any kind of preservatives or treatments to ensure the longevity of your outdoor teak.

NEW FURNITURE

All our teak furniture are sanded and polished at delivery – but that's it. If you're using the furniture outside, and they are exposed to water, they will get a bit rough. This is a natural process and is solved by sanding the teak. It usually only happens twice, in the beginning.

DON'T OIL OUTDOOR TEAK FURNITURE

Oiling teak is a good thing if you are planning on using the furniture indoors. Outdoor teak furniture should not be oiled. It will not make it last longer, but it will tie you into a tiresome maintenance routine. Oiled teak is more likely to mildew and will cause irregular coloring as it weathers.

New teak furniture often appears smooth and "polished" – this comes from the oil that occurs naturally in the wood. The oil on the surface of your teak will gradually evaporate when the furniture is outdoors (this is what happens when it turns grey). It's the oil that remains below the surface that gives the wood its strength and durability.

This is why Skargaarden teak can be left outside all year long.

SOME SHADES OF GREY

As mentioned already, left outdoors, our teak furniture will naturally weather to a silver grey color. You will begin to notice this "greying" in a few months, depending on the amount of sun and rain your furniture is exposed to. During the weathering process there may be some roughening of the grain, occurring in spots. You may even notice a few small cracks. Water spots or other discoloration may also occur

during the weathering process. All these flaws will eventually even out, and the furniture will take on a uniform silver-grey color. It's a natural, living material.

HOW TO KEEP THE ORIGINAL COLOR

So, what if you don't fancy the grey color and want to keep the original dark color of the teak? Your piece of furniture can be restored, by cleaning it with mild, soapy water and a soft bristle scrub brush. A good teak cleaner is also very effective. It requires no heavy scrubbing or polishing. A teak sealer can then be applied after cleaning, which will help to maintain the honey-like color of your teak. Teak sealer needs to be reapplied about once a year, and should not be applied to new teak. Remember to wipe your teak furniture clean with water and a mild detergent and then let it dry – before you apply the sealer. Apply the sealer in a thin layer! Less is really more.

OTHER TIPS FOR PROTECTING AND CARING THE TEAK

Cleaning your teak furniture every now and then is a good thing. It helps maintaining the general appearance and prevents dirt from building up. Hosing it will do the trick, so it's not that much of an effort. Just don't use a high-pressure washer. As mentioned earlier, use a mild detergent and rinse afterwards. You may of course cover your furniture when you are not using it for a long period of time. That will help keep it clean and protected (especially in areas with a lot of tree sap or dust), but is not essential.

If you do choose to use protective covers, it is very important that you use only "breathable" covers that don't trap the humidity, but allow constant ventilation. If you're in a region with cold and snowy winters, we recommend you to store the furniture in a roof-covered place.

OUR MATERIALS

All our teak, leather and glass is selected from a long-term perspective of sustainability. Our teak comes from carefully selected approved plantations with the highest available quality. Our steel and aluminum products need no maintenance, apart from gentle cleaning every now and then.

Our outdoor fabrics are from Sunbrella and Serge Ferrari, both leading companies in the development of weather-resistant fabrics. We use outdoor high quality foam filling and Eurofoam in our cushions, that permits maximum water drainage and air circulation, to keep the cushions dry and fresh.