

HÄRINGE

A lounge range made in teak. Frames in brushed stainless steel or powder coated black. Outdoor cushions feature buttons and decorative stitching, so they aren't waterproof but they are beautiful. Cushions is made in Sunbrella fabrics for outdoor use.

✓ STOCK ITEM ✉ E-MAIL SALES@SKARGAARDEN.COM FOR LEAD TIME

MATERIAL AND COLOR GUIDE

WOOD



TEAK

METAL FRAME



BLACK PAINTED
STEEL FRAME
RAL 9005



STAINLESS
STEEL FRAME

FABRICS



WHITE
SUNBRELLA NATTE
NAT 10020 140



GREY CHINÉ
SUNBRELLA NATTE
NAT 10022 140



HEATHER GREY
SUNBRELLA NATTE
SJA 10029 140



SOOTY
SUNBRELLA NATTE
NAT 10030 140



NATURE GREY
SUNBRELLA NATTE
NAT 10040 140



BLACK
SUNBRELLA NATTE
NAT 10078 140



HEATHER CHINÉ
SUNBRELLA NATTE
NAT 10039 300

HÄRINGE ARMCHAIR

Design Carl Jägnefeldt &
Joacim Wahlström



EU

PRODUCT

W:62,5 D:57 H:72
Seat height: 45
Armrest height: 72
Weight: 11 kg

PACKAGING

W:70 D:65 H:80
Weight: 16 kg
Volume: 0,37
1 pc per box

CUSHIONS

W:56 D:53 H:14
Weight: 2,5 kg
Volume: 0,042
1 pc per box

US

PRODUCT

W:24.5" D:22.5"
H:28.5"
Armrest height: 28.5"
Seat height: 17.5"
Weight: 24.25 lb

PACKAGING

W:27.0" D:25.0" H:31.5"
Weight: 35.27 lb
Volume: 0.36
1 pc per box

DESCRIPTION

- ✓ Black stainless steel frame with teak slats
- ✉ Brushed stainless steel frame with teak slats
- ✓ Nature Grey Natte cushions
- ✉ White Natte cushions
- ✉ Grey Chiné Natte cushions
- ✉ Heather Grey Natte cushions
- ✉ Sooty Natte cushions
- ✉ Heather Chiné Natte cushions
- ✉ Black Natte cushions

ITEM NO

HARAR-BT
HARAR-T
HAC-10040-SN-NG
HAC-10020-SN-W
HAC-10022-SN-GC
HAC-10029-SN-HG
HAC-10030-SN-S
HAC-10039-SN-HC
HAC-10078-SN-B

TEAK MAINTENANCE

Teak is a hardwood tree, called *Tectona grandis* in latin. Apart from being very stylish, it's also exceptionally durable and it needs very low maintenance. Do note, however, that the latter isn't the same as "no maintenance". Below are a few tips on what to do, and what not to do.

At Skargaarden we only use only high grade teak, harvested from carefully controlled plantations. You don't have to use any kind of preservatives or treatments to ensure the longevity of your outdoor teak.

NEW FURNITURE

All our teak furniture are sanded and polished at delivery – but that's it. If you're using the furniture outside, and they are exposed to water, they will get a bit rough. This is a natural process and is solved by sanding the teak. It usually only happens twice, in the beginning.

DON'T OIL OUTDOOR TEAK FURNITURE

Oiling teak is a good thing if you are planning on using the furniture indoors. Outdoor teak furniture should not be oiled. It will not make it last longer, but it will tie you into a tiresome maintenance routine. Oiled teak is more likely to mildew and will cause irregular coloring as it weathers.

New teak furniture often appears smooth and "polished" – this comes from the oil that occurs naturally in the wood. The oil on the surface of your teak will gradually evaporate when the furniture is outdoors (this is what happens when it turns grey). It's the oil that remains below the surface that gives the wood its strength and durability.

This is why Skargaarden teak can be left outside all year long.

SOME SHADES OF GREY

As mentioned already, left outdoors, our teak furniture will naturally weather to a silver grey color. You will begin to notice this "greying" in a few months, depending on the amount of sun and rain your furniture is exposed to. During the weathering process there may be some roughening of the grain, occurring in spots. You may even notice a few small cracks. Water spots or other discoloration may also occur

during the weathering process. All these flaws will eventually even out, and the furniture will take on a uniform silver-grey color. It's a natural, living material.

HOW TO KEEP THE ORIGINAL COLOR

So, what if you don't fancy the grey color and want to keep the original dark color of the teak? Your piece of furniture can be restored, by cleaning it with mild, soapy water and a soft bristle scrub brush. A good teak cleaner is also very effective. It requires no heavy scrubbing or polishing. A teak sealer can then be applied after cleaning, which will help to maintain the honey-like color of your teak. Teak sealer needs to be reapplied about once a year, and should not be applied to new teak. Remember to wipe your teak furniture clean with water and a mild detergent and then let it dry – before you apply the sealer. Apply the sealer in a thin layer! Less is really more.

OTHER TIPS FOR PROTECTING AND CARING THE TEAK

Cleaning your teak furniture every now and then is a good thing. It helps maintaining the general appearance and prevents dirt from building up. Hosing it will do the trick, so it's not that much of an effort. Just don't use a high-pressure washer. As mentioned earlier, use a mild detergent and rinse afterwards. You may of course cover your furniture when you are not using it for a long period of time. That will help keep it clean and protected (especially in areas with a lot of tree sap or dust), but is not essential.

If you do choose to use protective covers, it is very important that you use only "breathable" covers that don't trap the humidity, but allow constant ventilation. If you're in a region with cold and snowy winters, we recommend you to store the furniture in a roof-covered place.

OUR MATERIALS

All our teak, leather and glass is selected from a long-term perspective of sustainability. Our teak comes from carefully selected approved plantations with the highest available quality. Our steel and aluminum products need no maintenance, apart from gentle cleaning every now and then.

Our outdoor fabrics are from Sunbrella and Serge Ferrari, both leading companies in the development of weather-resistant fabrics. We use outdoor high quality foam filling and Eurofoam in our cushions, that permits maximum water drainage and air circulation, to keep the cushions dry and fresh.

SUNBRELLA UPHOLSTERY CARE AND CLEANING

To keep Sunbrella fabrics looking good, the best thing is to brush off dirt before it becomes embedded in the fabrics and wipe up spills or clean soon after a stain occurs. The quicker you clean spills and stains, the easier they can be to remove.

OUTDOOR UPHOLSTERY

Should there be a new spill or stain on your Sunbrella fabric, try the following first:

- Blot (don't rub) liquid spills with a clean, dry cloth. For oil-based spills, apply an absorbent such as corn starch, then remove with a straight edge.
- Spray on a mild cleaning solution of soap (such as Dawn or Woolite) and water.
- Rinse the fabric thoroughly to remove all soap residue. Then air dry.

If this doesn't get the stain completely out, here's how to clean the fabric:

CLEANING REMOVABLE FABRIC

Skargaarden strongly recommend hand washing of all Sunbrella fabrics. Soak fabric in a solution of 1/4 cup mild soap per gallon of lukewarm water. Use a sponge or very soft bristle brush to lightly agitate the stain. Then rinse thoroughly to remove all soap residue, and allow fabric to air dry.

CLEANING NON-REMOVABLE FABRIC

Prepare a solution of 1/4 cup mild soap per gallon of lukewarm water. Use a soft bristle brush to clean, allowing the cleaning solution to soak into the fabric. Rinse thoroughly to remove all soap residue and allow fabric to air dry.

MOLD AND MILDEW STAINS

Sunbrella fabrics do not promote mildew growth, however, mildew may grow on dirt and other foreign substances if not removed from the fabric. To remove mold or mildew:

- Prepare a solution of 1 cup of bleach and 1/4 cup mild soap per gallon of water.
- Spray on entire area and allow to soak into the fabric for 15 minutes.
- Clean entire surface area with a sponge, clean towel or very soft bristle brush.
- Rinse thoroughly to remove all soap residue.
- Air dry.

For severe mold/mildew growth, bleach quantities may be increased. It is best to clean the entire surface area of the fabric to avoid water rings and stains.

For information on cleaning other popular stains, see the Sunbrella Stain Chart. www.sunbrella.com/stainchart

