

Intercom IC-100-J Instruction Manual

Rev 1.0

ROSSO Racing wishes to thank you for your choice!

For further clearance and support, do not hesitate to contact us to the addresses you can find on the bottom of this page.

FEATURES

- Single volume knob adjustment
- Camera car video cable
- Quick access 9V battery vane
- Jack 6.35mm female connectors
- Easy fix on roll bar and dashboard

WHAT'S IN THE BOX

- 1 pc Intercom IC-100-J
- 1 pc Instruction manual
- 2 pc Audio cable, L=2mt/ea.
- 1 pc 12V power cable, L=1,5mt
- 1 pc Camera Car video cable, L=0.1mt

HOW IT WORKS

IC-100-J Intercom can be easily installed on a roll bar with the supplied adjustable plastic clamps. The unit can be also safely fixed to a rigid panel (dashboard, side bulkheads) using the 2 holes in the bottom side of the Intercom enclosure.

IC-100-J Intercom works either with 9V batteries and 12V car battery. In the latter case, a 9V battery can be eventually hosted in the vane with no failure brought to the unit.

IC-100-J Intercom can be powered on by switching the knob clockwise. A click will be heard and the red led will turn on as well. Adjust the knob to achieve the desired volume, which is the same for Driver and Co-driver. It's recommended to power off the unit after use to keep fresh the battery. In case of long period of inactivity, it's recommended to remove the battery.



OPTIONAL ACCESSORIES

IC-100-J Intercom can be used along a variety of helmets, find the proper compatibility in the table here.

✓ **COMPATIBLE HELMET**

✗ **NOT COMPATIBLE HELMET**

The eventual code shown in the table stands for the ROSSO Racing adapter required for a proper use.

Browse rosso-racing.com website for more informations.

COMPATIBILITY MATRIX	STILO WRC	STILO TROPHY PLUS	STILO TROPHY RALLY	OMP JET CARBON	OMP JET-10	OMP JET-7	PELTOR G89 G79	SPARCO PRO WTX	BELL MAG1 PRO
ROSSO									
IC-10-ROS/OMP/PEL	HEX-MM2	HEX-MM2	X	HEX-MM1	✓	X	✓	✓	✓
IC-10-STI	✓	✓	X	HEX-MF2	HEX-FF2	X	HEX-FF2	HEX-FF2	HEX-FF2
IC-200-ROS/OMP/PEL	HEX-MM2	HEX-MM2	X	X	✓	X	✓	✓	✓
IC-200-STI	✓	✓	X	X	HEX-FF2	X	HEX-FF2	HEX-FF2	HEX-FF2
IC-100-N	HEX-MM2	HEX-MM2	X	X	✓	X	✓	✓	✓
IC-100-S	✓	✓	X	X	HEX-FF2	X	HEX-FF2	HEX-FF2	HEX-FF2
IC-100-J	X	X	JAC-MM	X	X	✓	X	X	X

Manuale Istruzioni Intercom IC-100-J

Rev 1.0

ROSSO Racing ringrazia per la preferenza accordatoci!

Per eventuali chiarimenti, non esitate a contattarci ai recapiti indicati in fondo a questa pagina.

CARATTERISTICHE

- Singolo potenziometro volume
- Cavo collegamento camera car
- Vano porta batteria 9V con accesso rapido
- Connettori Jack 6.35mm Femmina
- Attacco a rollbar e cruscotto con fascette riapribili

DOTAZIONE

- N.1 Intercom IC-100-J
- N.1 Foglio istruzioni
- N.2 Cavo audio L=2mt/cad.
- N.1 Cavo 12V L=1,5mt
- N.1 Cavo Camera Car L=0.1mt

FUNZIONAMENTO

L'Intercom **IC-100-J** si fissa facilmente al roll bar per mezzo delle fascette riapribili in dotazione, al cruscotto e in generale su qualunque superficie piana grazie ai 2 fori passanti per il passaggio delle viti.

L'Intercom **IC-100-J** funziona sia con batteria 9V sia con alimentazione esterna (max 18V). Non è necessario rimuovere la pila 9V in caso di collegamento alla batteria dell'auto.

Ruotando la manopola del volume, il led rosso si accende e l'Intercom **IC-100-J** inizia a funzionare. Regolare il volume (identico per entrambi i canali Pilota e Co-pilota) ruotando la manopola fino al livello desiderato. Al termine dell'utilizzo, si consiglia di ruotare la manopola su OFF fino ad udire un click per salvaguardare l'autonomia della batteria.



ACCESSORI OPZIONALI

L'Intercom **IC-100-J** può essere usato coi caschi riportati nella tabella pubblicata a lato.

✓ **CASCO COMPATIBILE**

X **CASCO NON COMPATIBILE**

Il codice indica l'adattatore ROSSO Racing richiesto per avere la compatibilità con quel casco. Consultare il sito rosso-racing.com per maggiori informazioni

COMPATIBILITY MATRIX	STILO WRC	STILO TROPHY PLUS	STILO TROPHY RALLY	OMP JET CARBON	OMP JET-10	OMP JET-7	PELTOR G89 G79	SPARCO PRO WTX	BELL MAG1 PRO
ROSSO									
IC-10-ROS/OMP/PEL	HEX-MM2	HEX-MM2	X	HEX-MM1	✓	X	✓	✓	✓
IC-10-STI	✓	✓	X	HEX-MF2	HEX-FF2	X	HEX-FF2	HEX-FF2	HEX-FF2
IC-200-ROS/OMP/PEL	HEX-MM2	HEX-MM2	X	X	✓	X	✓	✓	✓
IC-200-STI	✓	✓	X	X	HEX-FF2	X	HEX-FF2	HEX-FF2	HEX-FF2
IC-100-N	HEX-MM2	HEX-MM2	X	X	✓	X	✓	✓	✓
IC-100-S	✓	✓	X	X	HEX-FF2	X	HEX-FF2	HEX-FF2	HEX-FF2
IC-100-J	X	X	JAC-MM	X	X	✓	X	X	X