


Thank you for purchasing our products. The default account status of this product is none and any fingerprint can be used to unlock. Your finger will become the key after configuring the settings of the lock as per the instructions given in the user manual. The first user's fingerprint is the administrator's fingerprint, and any new subsequent fingerprint need to be confirmed by administrator.

## Indicator


Different indicator represents different devices and status. Please check the details as below chart:

| Indicator Status                        | Indicator Status                              |
|-----------------------------------------|-----------------------------------------------|
| Low power                               | Red light and blue lights flashed alternately |
| Charging                                | Blue lights breathe brightly                  |
| Full charged                            | Blue light always on                          |
| Fingerprint acquisition mode            | Flash blue light for 3 times                  |
| Fingerprint collection successful       | Blue light                                    |
| Administrator fingerprint authorization | Red blue light                                |
| Unlock success                          | Blue light                                    |
| Delete fingerprint mode                 | Red light                                     |
| Failed to collect fingerprint           | Red light                                     |

## Collect fingerprint tips




## Description of first administrator's fingerprint record



## Fingerprint recording instructions

(The first and second fingerprints are the administrator fingerprint by default.)



## Delete fingerprint/Factory Reset



## Question

| Question                                                    | Reason                                           | Solution                                        |
|-------------------------------------------------------------|--------------------------------------------------|-------------------------------------------------|
| Touch the fingerprint sensor, The indicator light is not on | No power                                         | Please charge the fingerprint padlock           |
|                                                             | Stand by                                         | Please touch the fingerprint reader             |
| Can not be rechargeable                                     | Is there any foreign matter at the charging port | Please keep the charging port clean and tidy    |
| Can not unlock                                              | Your finger is too dry.                          | Please rub or breathe on your fingers           |
|                                                             | Your fingers are too wet                         | Please wipe the sweat or water off your fingers |
|                                                             | Dirty fingerprints                               | Please keep your fingers clean                  |
|                                                             | The fingerprint sensor is not clean              | Please wipe off the fingerprint reader.         |

## Features of functions

- [ Your fingerprint is the key.]  
Fingerprint Unlock, convenient.
- [ High Capacity]  
Support 20 sets fingerprints
- [ Waterproof and dustproof]  
Up to IP65 level waterproof can prevent the dust and rain efficiently.
- [ 1 second to unlock]  
Super CPU, good recognition, low error rate.
- [ Low power consumption]  
Full charge can provide 3000 switch lock operation.

Tack för att du köpt vår produkt.


Standardkontostatusen för denna produkt är ingen och vilket fingeravtryck som helst kan användas för att låsa upp. Ditt finger kommer att bli nyckeln när du konfigurerat inställningarna för låset enligt anvisningarna i användarhandboken. Den första användarens fingeravtryck är administratörens fingeravtryck och alla eventuella nya efterföljande fingeravtryck måste bekräftas av administratören.

## Indikator


Olika indikatorer representerar olika enheter och status. Var god kontrollera informationen i nedanstående tabell:

| Indikatorstatus                                  | Indikatorstatus                           |
|--------------------------------------------------|-------------------------------------------|
| Låg ström                                        | Rött ljus och blå ljus blinkar omväxlande |
| Laddar                                           | Blå ljus blinkar ljusst                   |
| Fulladdad                                        | Blå ljus tänd hela tiden                  |
| Fingeravtrycksregistreringsläge                  | Blå ljus blinkar 3 gånger                 |
| Registrering av fingeravtryck lyckad.            | Blått ljus                                |
| Auktorisering med administratörens fingeravtryck | Röd-blått ljus                            |
| Upplåsning framgångsrik                          | Blått ljus                                |
| Radera fingeravtrycksläge                        | Rött ljus                                 |
| Registrering av fingeravtryck ej lyckad          | Rött ljus                                 |

## Tips för att registrera fingeravtryck




## Beskrivning av den första administratörens fingeravtrycksregistrering



## Anvisningar för fingeravtrycksregistrering

((De första och andra fingeravtrycken är administratörens fingeravtryck som standard.))



## Ta bort fingeravtryck/Fabriksåterställning



## Fråga

| Fråga                                                     | Orsak                                             | Lösning                                              |
|-----------------------------------------------------------|---------------------------------------------------|------------------------------------------------------|
| Vidrar fingeravtrycks-Sensorn, Indikatorljuset är inte på | Ingen ström                                       | Var god ladda fingeravtrycksställsläset              |
|                                                           | Stand by                                          | Var god vidrar fingeravtrycksställsläset             |
| Kan inte laddas upp                                       | Finns det något främmande ämne på laddningsporten | Håll laddningsporten ren och fin                     |
| Kan inte låsa upp                                         | Fingret är för torrt.                             | Gnugga eller andas på fingrarna                      |
|                                                           | Fingrarna är för fuktiga                          | Var god torka bort vatten eller svett från fingrarna |
|                                                           | Smutsiga fingeravtryck                            | Håll fingrarna rena                                  |
|                                                           | Fingeravtryckssensorn är inte ren                 | Torka av fingeravtrycksläsaren.                      |

## Funktionsegenskaper

- [ Ditt fingeravtryck ] är nyckeln.] Upplåsning med fingeravtryck, bekvämt.
- [ Hög kapacitet ] Stöd för 20 uppsättningar av fingeravtryck
- [ Vattentät och dammtät ] Vattentät upp till IP65; kan effektivt stoppa regn och damm.
- [ 1 sekund för att låsa upp ] Super-CPU, bra igenkänning, låg frekvens
- [ Låg strömförbrukning ] Full laddning kan ge 3 000 låsöppningsoperationer.