

# Tork Constant Air Freshener Dispenser

Elevation  
Design

Tork diffuseur de désodorisant  
permanent

Tork Spender für  
Kontinuierlichen Lufterfrischer





A3




[www.torkglobal.com](http://www.torkglobal.com)

**TORK**


Tork Constant Air Freshener Dispenser




2






3







4









Please make sure that the dispenser is installed/mounted in an upright position before inserting the refill to ensure proper functioning.

## Alt 2





Please make sure that the dispenser is installed/mounted in an upright position before inserting the refill to ensure proper functioning.


Tork Constant Air Freshener Dispenser




9








10



11





12




2 min

Tork Constant Air Freshener Dispenser


1




2





3



4




1



2



2 x AA LR6



## **EN Cleaning instructions**

- Use mild cleaners. Wipe with cloth using soap and water. Do not use abrasives. Dispenser is not dishwasher safe.

## **DE Reinigungsanweisungen**

- Milde Reinigungsmittel verwenden. Abwischen mit einem Tuch unter Verwendung von Wasser und Seife. Keine Scheuermittel verwenden. Spender ist nicht spülmaschinenfest.

## **FR Instructions de nettoyage**

- Utiliser des nettoyeurs non agressifs. Nettoyer avec chiffon, de l'eau et du savon. Ne pas utiliser d'agents abrasifs. Le distributeur n'est pas conçu pour au lave-vaisselle.

## **EN Refill Recycling Information**

- For safety handling please read the safety data sheet Must be disposed off as hazardous waste in accordance to local regulations.