




Assembly instructions
Monteringsanvisning



Components

Delar

1. Backrest, ryggstöd
2. Seat, sits
3. Screws for backrest attachment
4. Short screw, kort skruv
5. Mechanism, mekanism
6. Screws for seat attachment
7. Screws for seat attachment
8. Metal ring, bricka
9. Long screw, lång skruv
10. Gas lift, gaskolv
11. Screws for base attachment
12. Telescopic gas lift cover, gaskolvsöverdrag
13. Screws for base attachment
14. Screws for base attachment
15. Base, kryss
16. Wheel, hjul