

CARSON[®]

MagniFlash[™]

CP-40

9x LED Lighted Magnifier / Flashlight

Congratulations on selecting your new Magniflash! In order to achieve optimum performance, please follow instructions for proper use and care.




PRODUCT SPECIFICATION

Magnification:	11x	Dimensions:	5.3" x 2.4" x 1.0"
Lens Diameter:	42mm (1.6")	Batteries:	3 AAA
Weight:	0.15 lbs	Accessories:	Neck Strap and Case

INSTALLING BATTERIES

Remove battery door and insert 3 AAA batteries with the correct polarity. Reattach battery door when through.



Warning: Mixing old and new, different brands or types within brands may cause batteries to leak, overheat or explode. Keep away from fire or excessive heat. Inspect batteries for corrosion or leakage. Use alkaline batteries only. Insert in direction indicated.

USING MAGNIFIER


Place magnifier over the subject you are viewing.

For Best Results:

- Depending on your vision, you may need to move the magnifier closer or further away until focused.

USING LIGHTS

1. Slide switch up to use Magnifier Light.
2. Slide switch down to use Flashlight.
3. Slide switch to center position to turn either light off.



CARE

Clean using microfiber lens cloth. Do not use any abrasives, chemical cleaners, or solvents.

Customer Service:

If you experience any difficulties, please contact us and we will be happy to help you.



✉ info@carson.com



✉ uksupport@carson.com



✉ eusupport@carson.com

For warranty information, visit www.carson.com/warranty

www.carson.com

Carson Optical 2070 5th Avenue, Ronkonkoma, NY 11779
Tel: 631-963-5000