

Quick installation guide



Mount the speaker in the track.

Make sure it's in the correct position.

Select phase 1,2 or 3 depending on the installation of power in the track.



When correct phase is selected the power LED comes on and the speaker is powered.




Select a channel. Default chanel is 50 and can be used if there is no other Loud of Sweden system using it in the same area. In case two systems share channel there will be no sound as they occupy the same space.




Each speaker has a individual volume control.


Normal level is 0, but can be adjusted from -9 to +9.



Adjust the speakers position and lock it in tp place.



S1 Satelite speaker is now installed.
Install the B1 transmitter unit before you install any additional S1 speakers



Plug in the B1 Transmitter/volume control to a power outlet



Plug in the audio cable in the "Line in" connection.

The oposit end is plugged in to your device of choice from which you play your music.




Press both CH buttons simultaneously for 3 seconds to select the same channel as the S1 speaker. When the red digits stops flashing the channel has been set.



Push talk button and make your announcement when the green light is on. If you can hear the voice in the speaker, the system is installed correctly.



Adjust volume with the up or down button. The green display indicates selected volume.



Your B1 is now installed. You can now proceed to install additional S1 speakers.