
Assembly Instructions



MULTIFUNCTIONAL COUNTER


This manual covers the assembly principles for the multifunctional counters. The configuration shown in the illustrations is for reference only. Actual module combinations, shelf quantities, cabinet modules, and accessory placement may vary depending on the ordered configuration.

2026-11-03

If any part is damaged and requires replacement, or if you have any questions, please contact Senab Concept at bmwgroup.distribution@senab.com

Contact info:
bmwgroup.distribution@senab.com

Multifunctional counter
configurations


BMWE3101554S	Multifunctional counter with one workstation	
BMWE3101853S	Multifunctional counter with two workstations	
BMWE3101854S	Multifunctional counter with three workstations	


Note: Variation may occur depending on the ordered solution.

Multifunctional Counter

1.

Place start & end gables on desired distance






Note: The assembly shown in this manual illustrates shelf BMWE3101853S Part numbers and component configuration may vary depending on the ordered configuration.

Multifunctional Counter

2.


Loosen the panel on wall modules




Note: The assembly shown in this manual illustrates shelf BMWE3101853S Part numbers and component configuration may vary depending on the ordered configuration.

Multifunctional Counter

3.






Note: The assembly shown in this manual illustrates shelf BMWE3101853S Part numbers and component configuration may vary depending on the ordered configuration.

Multifunctional Counter


4.



Note: The assembly shown in this manual illustrates shelf BMWE3101853S Part numbers and component configuration may vary depending on the ordered configuration.

Multifunctional Counter

5.




Note: The assembly shown in this manual illustrates shelf BMWE3101853S Part numbers and component configuration may vary depending on the ordered configuration.

Multifunctional Counter

6.


Fasten the panel on wall modules




Note: The assembly shown in this manual illustrates shelf BMWE3101853S Part numbers and component configuration may vary depending on the ordered configuration.

Multifunctional Counter

7.






Note: The assembly shown in this manual illustrates shelf BMWE3101853S Part numbers and component configuration may vary depending on the ordered configuration.

Multifunctional Counter

8.




Make sure that the table top sides are flush with the cabinets sides.

Note: The assembly shown in this manual illustrates shelf BMWE3101853S Part numbers and component configuration may vary depending on the ordered configuration.

Multifunctional Counter


9.



Note: The assembly shown in this manual illustrates shelf BMWE3101853S Part numbers and component configuration may vary depending on the ordered configuration.

Multifunctional Counter


10.





Note: The assembly shown in this manual illustrates shelf BMWE3101853S Part numbers and component configuration may vary depending on the ordered configuration.

Multifunctional Counter

11.








Note: The assembly shown in this manual illustrates shelf BMWE3101853S Part numbers and component configuration may vary depending on the ordered configuration.

Multifunctional Counter


12.



Note: The assembly shown in this manual illustrates shelf BMWE3101853S Part numbers and component configuration may vary depending on the ordered configuration.

Multifunctional Counter


13



Note: The assembly shown in this manual illustrates shelf BMWE3101853S Part numbers and component configuration may vary depending on the ordered configuration.

Multifunctional Counter


14.




Place the transformer under or inside the cabinet, Connect the led.

Note: The assembly shown in this manual illustrates shelf BMWE3101853S Part numbers and component configuration may vary depending on the ordered configuration.

Multifunctional Counter








Note: The assembly shown in this manual illustrates shelf BMWE3101853S Part numbers and component configuration may vary depending on the ordered configuration.

Multifunctional counter

parts

BMWE3101536S	Multifunctional Counter / Bar Counter End element left/right	
BMWE3102522S	Multifunctional Counter / Bar Counter Front element straight counter 2400mm	
BMWE3101540S	Multifunctional Counter / Bar Counter Front element straight counter 1600mm	
BMWE3101538S	BMW Sales Shelf L-Variant Kit 2/600mm	
BMWE3101537S	Multifunctional Counter / Bar Counter Finishing element/corner section (90° quarter circle)	



Multifunctional counter

parts

BMWE3101555S	Bar counter top wooden 2400mm	
BMWE3101541S	Multifunctional Counter top 1600mm wood	
BMW5018S	Height-adjustable desk 1580x650	

Multifunctional counter

parts

BMWE3101550S	Multifunctional Counter printer sideboard with printer drawer	
BMWE3501549S	Multifunctional Counter sideboard with a door and paper trays	
BMWS00075	MF counter desk workstation cabinet	
BMWS00076	MF counter desk workstation drawer	
BMWS00077	MF counter desk workstation Top	