


CAUTION! Make sure machine is unplugged from electrical current. For a correct cleaning process please follow the instructions bellow.



1. Take off the front cover.



2. Remove the Self-Service tap.



3. Take out the filter.



4. Take out the peel guides.



5. Extract the knife by pulling it towards you.
CAUTION! The blade is very sharp, be careful not to cut yourself.



6. Pull off the peel ejectors.




7. Unscrew the securing knobs of the pressing units.



8. Take off the pressing units in pairs.



9. Remove the chute of the podium.



10. Empty peel bin.



INFORMATION: All pieces, **EXCEPT THE FRONT COVER**, can be cleaned in a dishwasher. The juice extraction zone and the front cover should be cleaned using a moist cloth and dish washing liquid. Rinse with clean water to remove any washing liquid traces.



11. Replace the dismantled pieces with clean ones.



12. Mount the chute.



13. Mount the pressing units by pairs.



14. Fix the knobs and tighten then well. **Missing knobs are to be replaced immediately. Never operate the machine with any knob missing.**



15. Put on the peel ejectors. **Push them firmly to assure their right positioning in order to avoid breakage while using the machine.**



16. Put on the knife. Push until it clicks into place with a “click”.



17. Mount the peel guides.



18. Insert the juice filter.



19. Screw the Self-Service tap into its position.



20. Place the front cover.