



Note: Torque Tester and Torque Wrench are not included.

Item No.	Max.Torque N.m	Arm Length		Length mm	Width mm	Height mm	Weight kg
		Min(mm)	Max(mm)				
TSI350	350	197	686	860	290	590	32.5
TSI1100	1100	380	1350	1760	350	590	76
TSI2000	2000	420	1690	2090	350	590	80

Customized for special requirements.

• TS Manual Loader for torque wrench testing

- Large diameter wheel for easy and smooth application of torque.
- Different load cells may be used, some requiring special mounting adapters.
- Instrument rack tray is adjustable for comfort and good visibility.
- Can be adjusted to accommodate different wrench lengths and heights.
- Torque Tester and Torque Wrench are not included.



• TEM Torque Tester

Item No.	Square Drive	Torque Range		Outer Diameter mm	Height mm	Weight kg
		N.m	Lb.ft			
TEM225	3/8"	2.5-25	1.8-18	102	77	2.3
TEM240	3/8"	4.0-40	3.0-30	102	77	2.33
TEM275	3/8"	7.5-75	5.5-55	102	77	2.37
TEM3150	1/2"	15-150	11-110	102	77	2.44
TEM3250	1/2"	25-250	18.4-184	102	77	2.52
TEM3400	1/2"	40-400	29.5-295	102	77	2.44
TEM4650	3/4"	65-650	48-480	136	103	2.54
TEM41250	3/4"	125-1250	92.2-922	136	103	2.73
TEM52500	1"	250-2500	184.5-1845	136	103	3.01

- Accuracy: $\pm 0.5\%$ from 10% to 100% of capacity
- 7 Inch color touch screen
- Menu easy to operate
- Languages available: Chinese or English
- 8 Units: N.m; cN.m; kgm; ckgm; Lb.ft; Lb.in; Oz.in
- Three modes: First Peak, Peak, Track
- Three interfaces: regular, preset, waveform
- During the wrench test, 15 test data will be automatically stored
- Stores up to 5000 test data
- 100 sets of parameters can be preset
- Continuous test, automatically clear to zero
- Overload warning signal
- Upload data by USB port
- Remote parameter correction
- Automatic shutdown in 5 minutes without operation