



Produktfamilj
Laser Lite Single-Use Earplug
Highly visible protection



Product Numbers & Ordering Information

	33 011 06	Laser Lite - corded SNR 35 H - 34 M - 32 L - 31
	33 011 05	Laser Lite - uncorded SNR 35 H - 34 M - 32 L - 31
	10 130 47	Laser Lite - uncorded bulk refill for Leight Source 400 SNR 35 H - 34 M - 32 L - 31
	33 012 71	Laser Lite - uncorded bulk refill for Leight Source 500 SNR 35 H - 34 M - 32 L - 31

Översikt

Viktigaste egenskaperna

- Vibrant colors make protection visible
- Self-adjusting polyurethane foam expands to fit virtually every wearer
- Contoured T-shape for easy insertion and wear
- Smooth, soil-resistant closed cell-foam skin prevents dirt build-up
- Available in paper bag packaging and/or with cotton cords for process industries [pulp & paper]
- Bulk refills for Leight Source 400 and Leight Source 500 Earplug Dispensers save time, waste and space

Rekommenderade branscher/rekommenderat användningsområde

- Jordbruk
- Kemi
- Byggindustri
- Brandskydd
- Skogsvård
- Myndigheter
- Polis
- Tillverkning
- Sjukvård
- Militären
- Gruvdrift
- Kommunala tjänster
- Olja och gas
- Läkemedel
- Stål och metaller
- Transport
- Vatten och energi
- Svetsning

Risker

- Buller

Föreskrifter

- 29 CFR 1910.95 - 29 CFR 1910.95
- S3.19-1974 - Attenuation Test Protocol (US)
- Part II, (R.S.C. 1985, c. L-2) - Canada Labour Code
- Z94.2-1994 - Attenuation Test Protocol (CAN)
- 2003/10/EC - EU Hearing Directive
- 89/686/EEC - EU Directive/PPE
- Category II - EC Category/PPE
- EN 352-2:1993 - EU Standards
- EN-24869-1:1993 - EU Standards
- NOHSC: 1007 (2000) - National Standard for Occupational Noise (AUS/NZ)
- NR 15 - Security and Health of Work, Annexes 1 and 2, n°3.214/1978 - Occupational Noise Regulations (BR)
- ANSI S12.6/1997 - Method B - Attenuation Test Protocol (BR)

Tidigare varumärke

Howard Leight

Specifikationer

Color	Magenta/Yellow
Shape	T-Shape
Material	Polyurethane Foam
Packaging Options	• Polybag • Paper Bag • Bulk Refill for Leight Source 400 or Leight Source 500 Dispenser
Cord Options	• Uncorded • Polycord • Cotton Cord
NRR	32
Canada Class	A(L)
SNR	35
SLC80	25 dB / Class 4

EU Certifications

- European Directives – 89/686/EEC
- EC Category PPE – Category II
- Standards – EN 352-2:1993 / EN-24869-1:1993
- EC Certification Number – 951095
- EC Attestation Number – 9503632
- Laboratory – B.G.I.A.

AUS Certifications

- Standardsmark License #1579

Trycksaker & dokument**CE Certificate - Laser Lite**http://www.honeywellsafety.com/Supplementary/Documents_and_Downloads/Secured/Hearing_F

CE Certificate - Laser Lite

**EC Attestation Report - Laser Lite**http://www.honeywellsafety.com/Supplementary/Documents_and_Downloads/Secured/Hearing_F

EC Attestation Report - Laser Lite

Earplug Instruction Poster - EN

http://www.honeywellsafety.com/Supplementary/Documents_and_Downloads/Hearing_Protection

Earplug Instruction Poster - ES

http://www.honeywellsafety.com/Supplementary/Documents_and_Downloads/Hearing_Protection

Earplug Instruction Poster - FR

http://www.honeywellsafety.com/Supplementary/Documents_and_Downloads/Hearing_Protection

Data Sheet Laser Lite Earplug LL-1, LL-LS4, LL-1-D, LL-30 - AUS

http://www.honeywellsafety.com/Supplementary/Documents_and_Downloads/Hearing_Protection

▶ ▶ ▶ LASER LITE™ EARPLUG PRODUCT INFORMATION Single-use shouldn't mean single choice. Howard Leight offers a comprehensive choice of Single-Use earplugs that include the comfort features your employees deserve, plus the highest SLC80 ratings available. An economical choice for work situations that demand a high degree

Noise Thermometer Poster - AUS

http://www.honeywellsafety.com/Supplementary/Documents_and_Downloads/Hearing_Protection

Earplug Fitting Poster - AUS

http://www.honeywellsafety.com/Supplementary/Documents_and_Downloads/Hearing_Protection

Care & Maintenance of Earplugs and Earmuffs - AUS

http://www.honeywellsafety.com/Supplementary/Documents_and_Downloads/Hearing_Protection

Training & Proper Use

1. With clean hands, roll the entire earplug into narrowest possible crease-free cylinder.
2. Reach over your head with a free hand, pull your ear up and back, and insert the earplug well inside your ear canal.
3. Hold for 30 – 40 seconds, until the earplug fully expands in your ear canal. If properly fitted, the end of the earplugs should not be visible to someone looking at you from the front.
4. Proper Fit – If either or both earplugs do not seem to be fitted properly, remove the earplug and reinsert
5. Removal – Gently twist earplug while slowly pulling in an outward motion for removal.
6. Acoustical Check – In a noisy environment, with earplugs inserted, cup your hands over your ears and release. Earplugs should block enough noise so that covering your ears with your hands should not result in a significant noise difference.

Ytterligare information

CARE + MAINTENANCE

- INSPECT – Inspect prior to fitting, examine your earplugs for dirt, damage or extreme hardness—discard immediately if compromised.
- DISCARD – For proper hygiene, discard Single-Use earplugs after use.
- HYGIENE – To maintain hygiene standards, Single-Use earplugs should be discarded at the end of every shift.

Honeywell

Välj region/land

© 2011 Honeywell International Inc.