



## Produktfamilj

# Sync Stereo Earmuff

Play It. Safe.

+  Visa fler

## Product Numbers & Ordering Information

|  |         |                                                     |
|--|---------|-----------------------------------------------------|
|  | 1030111 | <b>Sync Stereo Earmuff</b><br>SNR 31 H-31 M-28 L-23 |
|--|---------|-----------------------------------------------------|

## Förpackningsinformation

Clamshell

## Översikt

### Viktigaste egenskaperna

***Most stereo earmuffs provide some level of hearing protection.  
But often sacrifice sound quality for attenuation.***

That's why we created Sync, the latest innovation in passive hearing protection for active lifestyles. It's a stereo earmuff that's in Sync with proper levels of hearing protection, high-fidelity sound and your ability to listen to portable audio devices safely at work – and at home.

### Protection

## Sync Stereo Earmuff

- Volume Management Technology™ manages output volume from portable audio devices at 82 dBA\*
- Provides ideal protection from most low to medium hazardous noise levels
- Ideal for use at work and at home

### **Productivity**

- No batteries required – just plug in and go!

### **Personalized**

- Includes 3.5mm input cable, plugs into most MP3 players, mobile phones, and other personal audio devices

### **Performance**

- Technologically advanced acoustical bass chamber enhances bass sounds that are typically sacrificed in a stereo earmuff
- Balanced sound across frequencies eliminates the need to “crank up” the volume
- On-par sound quality of many professional and high-end personal stereo headphones

### **Style**

- Sleek diamond pattern headband looks cool, easy to clean
- Reinforced fork slides with handholds for easy and comfortable fit

*\*Based on sound output levels no greater than 126mV*

### **Föreskrifter**

- OSHA Occupational Noise Exposure 29 CFR 1910.95 - OSHA Occupational Noise Amendment
- ANSI S3.19-1974 - Attenuation Test Protocol (US)
- Part II, (R.S.C. 1985, c. L-2) - Canada Labour Code
- Z94.2-1994 - Attenuation Test Protocol (CAN)
- 2003/10/EC - EU Hearing Directive
- 89/686/EEC - EU Directive/PPE
- Category II - EU Category/PPE
- EN-352-1:2002 - EU Standards
- NOHSC: 1007 (2000) - National Standard for Occupational Noise

### **Tidigare varumärke**

Howard Leight

### **Garantiinformation**

There is a one year guarantee against defects in material and workmanship. The guarantee does not cover damage caused by misuse, abuse or unauthorised modifications. TO OBTAIN GUARANTEE, the guarantee certificate must be properly filled in by the dealer and then sent in together with the faulty product.

## Specifikationer

|                     |                 |
|---------------------|-----------------|
| <b>Dielectric</b>   | No              |
| <b>Earcup Color</b> | Black           |
| <b>Batteries</b>    | No              |
| <b>Packaging</b>    | Clamshell       |
| <b>NRR</b>          | 25              |
| <b>Canada Class</b> | A               |
| <b>SNR</b>          | 31              |
| <b>SLC80</b>        | 31 dB / Class 5 |

EU Certifications

- European Directives – 89/686/EEC
- EC Category PPE – Category II
- Standards – EN 352-1, 352-4, EN 352-6,
- EC Certification Number –
- EC Attestation Number –
- Laboratory – INSPEC

## Certifieringarna

 **CE Certificate - Sync Stereo Earmuff**

[http://www.honeywellsafety.com/Supplementary/Documents\\_and\\_Downloads/Secured/Hearing\\_F](http://www.honeywellsafety.com/Supplementary/Documents_and_Downloads/Secured/Hearing_F)

 **EC Attestation Report - Sync Stereo Earmuff**

[http://www.honeywellsafety.com/Supplementary/Documents\\_and\\_Downloads/Secured/Hearing\\_F](http://www.honeywellsafety.com/Supplementary/Documents_and_Downloads/Secured/Hearing_F)

## Trycksaker &amp; dokument

**Sync Brochure - USCAN**

[http://www.honeywellsafety.com/Supplementary/Documents\\_and\\_Downloads/Hearing\\_Protection](http://www.honeywellsafety.com/Supplementary/Documents_and_Downloads/Hearing_Protection)

Play it. Safe. Sperian Hearing Protection, 7828 Waterville Road San Diego, CA 92154 ph 800.430.5490 fax howardleight.com HLI.773 RPI 01/11 Most stereo earmuffs provide some level of hearing protection. But often sacrifice sound quality for attenuation. Sync™ That's why we created Sync™, the latest innovation in passive

**Sync Brochure - AUSNZ**

[http://www.honeywellsafety.com/Supplementary/Documents\\_and\\_Downloads/Hearing\\_Protection](http://www.honeywellsafety.com/Supplementary/Documents_and_Downloads/Hearing_Protection)

Play it. Safe. Sync™ Stereo Earmuff Ordering Information SKU Description Packaging Sync Stereo Earmuff Clamshell 12 EA per Case (2 EA per Inner Pack) 1030220 Hygiene Kit Polybag 10 PR/Box

## Sync Stereo Earmuff

(pair ear cushions and foam inserts) Sperian Protection Australia Pty Ltd 43 Garden Boulevard, Dingley, VIC 3172 ph: 1300 139 166 fa

### Sync Brochure - DE

[http://www.honeywellsafety.com/Supplementary/Documents\\_and\\_Downloads/Hearing\\_Protection](http://www.honeywellsafety.com/Supplementary/Documents_and_Downloads/Hearing_Protection)

Hören Sie Ihre Musik. Ganz sicher. Bestellinformationen Sync™ Stereo-Kapselgehörschützer Art.-Nr. Beschreibung Einzelpackung Umverpackung 10 301 11 Stereokapsel Sync Blister 2 Stck pro Karton 10 302 20 Hygieneset PE-Beutel 10 Sets pro Karton (ein Paar Dichtungskissen und Schaumstoffeinlagen) 10 172 10 Ersatz-Audiokabel 3,

### Sync Brochure - ES

[http://www.honeywellsafety.com/Supplementary/Documents\\_and\\_Downloads/Hearing\\_Protection](http://www.honeywellsafety.com/Supplementary/Documents_and_Downloads/Hearing_Protection)

Escuche su música. Con toda seguridad. Para pedir Sync™ Stereo Referencia Descripción Embalaje Presentación 10 301 11 Orejeras antiruido estereo Sync Blister 2 unidades por caja 10 302 20 Kit de higiene Bolsa de PE 10 pares por caja (par de almohadillas y piezas de espuma) 10 172 10 Cable audio Bolsa de PE 1 unidad de sust

### Sync Brochure - FI

[http://www.honeywellsafety.com/Supplementary/Documents\\_and\\_Downloads/Hearing\\_Protection](http://www.honeywellsafety.com/Supplementary/Documents_and_Downloads/Hearing_Protection)

Kuuntele musiikkia. Turvallisesti Sync™ stereokupusuojaimeen tilaustiedot Tuotenro Kuvaus Pakkaus 10 301 10 Sync-stereokupusuojaimeen Kupupakkaus Pari/rasia 10 302 20 Hygieniasarja Suojapussi 10 kpl/rasia pari korvapehmusteita ja vaahtomuovisiskkeitä) 10 172 10 3,5 mm varaosa Suojapussi 1 kpl njohto Usein nenlaatu kuitenkin

### Sync Brochure - FR

[http://www.honeywellsafety.com/Supplementary/Documents\\_and\\_Downloads/Hearing\\_Protection](http://www.honeywellsafety.com/Supplementary/Documents_and_Downloads/Hearing_Protection)

Ecoutez votre musique. En toute sécurité. Pour commander Sync™ Référence Description Emballage Conditionnement 10 301 11 Casque antibruit Stéréo Sync Blister 2 unités par carton 10 302 20 Kit d'hygiène Sachet en PE 10 paires par boîte (paire de coussinets et collierettes en mousse) 10 172 10 Câble audio Sachet en PE 1 unité de rem

### Sync Brochure - HU

[http://www.honeywellsafety.com/Supplementary/Documents\\_and\\_Downloads/Hearing\\_Protection](http://www.honeywellsafety.com/Supplementary/Documents_and_Downloads/Hearing_Protection)

Használat! Biztonság! Sync™ Sztereó Fültek Rendelési tudnivalók Cikkszám Megnevezés Csomagolás Kiszáratás 10 301 11 Sync Sztereó Fültek Fedelesek doboz 2 db/doboz 10 302 20 Higiénia készletek Nejlontások 10 pr/doboz (egy pr fülpárna s szivacsbettek) 10 172 10 3,5mm csatlakozó Nejlontások 1 db audio kábel A legjobb sztereó fültek biztosítják

### Sync Brochure - IT

[http://www.honeywellsafety.com/Supplementary/Documents\\_and\\_Downloads/Hearing\\_Protection](http://www.honeywellsafety.com/Supplementary/Documents_and_Downloads/Hearing_Protection)

Howard Leight Sync Stereo Earmuff

### Sync Brochure - NL

[http://www.honeywellsafety.com/Supplementary/Documents\\_and\\_Downloads/Hearing\\_Protection](http://www.honeywellsafety.com/Supplementary/Documents_and_Downloads/Hearing_Protection)

Luister veilig naar jouw muziek Hoe Sync™ Stereo bestellen? Art. nr. Omschrijving Verpakking 10 301 11 Oorkap Sync Stereo Blister 10 302 20 Hyginische kit PE zakje (paar schuimstof kussentjes en randjes) 10 172 10 Reserve audiokabel PE zakje 3,5mm De meeste oorkappen bieden wel bescherming, maar vaak ten koste van de g

### Sync Brochure - NO

[http://www.honeywellsafety.com/Supplementary/Documents\\_and\\_Downloads/Hearing\\_Protection](http://www.honeywellsafety.com/Supplementary/Documents_and_Downloads/Hearing_Protection)

Lytt. Sikkert. Bestillingsinformasjon for Sync™ stereo reklokke Art.nr. Beskrivelse Emballasje I forpakningen 10 301 10 Sync stereo reklokke Hardplast 2 stk. per kartong 10 302 20 Hygienesett Polybag 10 PR/Box (par reputer og skuminnlegg) 10 172 10 3,5 mm reserve-Plastpose 1 stk. lyd kabel De fleste stereo reklokker gir

### Sync Brochure - PL

[http://www.honeywellsafety.com/Supplementary/Documents\\_and\\_Downloads/Hearing\\_Protection](http://www.honeywellsafety.com/Supplementary/Documents_and_Downloads/Hearing_Protection)

Play it. Safe. Ochronniki słuchu Sync™ Informacje dotyczące zamawiania SKU Opis Opakowanie Konfiguracja 10 301 11 Sync Stereo Earmuff Blister 2 szt/opakowanie 10 302 20 Zestaw higieniczny Woreczek 10 par/pudełko (para poduszek nausznych z wkładem gombkowym) 10 172 10 3.5mm Wymienny Woreczek 1 sztuka Przewód audio Większ

**Sync Brochure - SE**

[http://www.honeywellsafety.com/Supplementary/Documents\\_and\\_Downloads/Hearing\\_Protection](http://www.honeywellsafety.com/Supplementary/Documents_and_Downloads/Hearing_Protection)

Lyssna. Och var på den skrä sidan. Sync™ Stereo-hrselkpor -beställningsinformation Art.nr.  
Beskrivning Frpackning Leveransfrpackning 10 301 10 Sync stereo-hrselkpor Blisterfrpackning 2  
st. per box 10 302 20 Hygiensats Plastpse 10 par/box (par med ttningsringar och insats av skum)  
10 172 10 3,5 mm utbytesdel Plastpse 1 st

**Sync Brochure - UK**

[http://www.honeywellsafety.com/Supplementary/Documents\\_and\\_Downloads/Hearing\\_Protection](http://www.honeywellsafety.com/Supplementary/Documents_and_Downloads/Hearing_Protection)

Play it. Safe. Sync™ Stereo Earmuff Ordering Information SKU Description Packaging 301 10 Sync  
Stereo Earmuff Clamshell 2 EA per Case 10 302 20 Hygiene Kit Polybag 10 PR/Box (pair ear  
cushions and foam inserts) 10 172 10 3.5mm Replacement Polybag 1 EA Audio Cable Most stereo  
earmuffs provide some level of hearing prote

**Training & Proper Use**

Listening to music, or any other sound, at a high volume over time can cause permanent damage to your hearing. Users should enjoy their favorite music safely and avoid the potential for hearing loss. We recommend that you listen responsibly, including listening at 80% of a device's maximum volume safely for a maximum of 90 minutes per day. If you listen at a lower volume, you can listen for longer. Noise-induced hearing loss is 100% permanent, but 100% preventable.

- **Fitting:** Place the ear cups over the outer ear. Adjust the headband by sliding the headband up or down at the attachment buttons. The ear cushions should seal firmly against the head.
- **Optimized Fit:** For best results, remove all hair under the cushion. Noise reduction will be adversely affected by anything that impairs the seal of the earmuff cushions against the head, such as thick spectacle frames, balaclavas, etc.

**WARNING**

***Listening to music, or any other sound at a high volume over time can cause permanent damage to your hearing.*** Users should enjoy their favorite music safely and avoid the potential for hearing loss. We recommend that you listen responsibly, including listening at 80% of a device's maximum volume safely for a maximum of 90 minutes per day. If you listen at a lower volume, you can listen for longer. ***Noise-induced hearing loss is 100% permanent, but 100% preventable.***

**Ytterligare information**

**CARE AND MAINTENANCE**

- **INSPECT** – Regularly examine earcups and ear cushions for cracks and leaks—discard if earcups are visibly damaged or compromised. Replace ear cushions if damaged.
- **CLEAN** – Wash earcups and ear cushions regularly with mild soap and water. They may not be dipped into water. Do not treat with any other substances, as the ear cushions may degrade and compromise use.
- **REPLACE** – As ear cushions and foam inserts can degrade over time, replace these every 6-8 months under normal wear, or every 3-4 months with heavy use or in humid/extreme climates.

**Honeywell**

Välj region/land

© 2011 Honeywell International Inc.